



388120538	Unterputz-Brause-Thermostatarmatur		concealed thermostatic shower mixer
1	7329105-00	UP - ROSETTE	ESCUTCHEON, CONCEALED
2	7328405-00	DRUCKTASTEN RUND	PUSH BUTTON ROUND
3	7328505-00	THERMOSTATGRIFF	HANDLE FOR THERMOSTAT
4	93012759-00	JUSTIERBUCHSE	SLEEVE FOR ADJUSTMENT
5	91726737-00	SPINDELVERLÄNGERUNG	SPINDEL SCREW EXTENSION
6	7329235-00	SCHRAUBEN SET	SCREW SET
7	7436500-00	THERMOSTAT	TEMPERATURE CONTROL UNIT
8	7479700-00	RÜCKFLUSSVERHINDERER	BACK FLOW PREVENTER
9	93016000-00	HÜLSE	SLEEVE
10	7301100-00	DICHTUNGSSATZ	SEALING SET